

Step one: preparing part

1. Be sure you have all the listed tools and components required before starting.



2. Unpack the components and place like pieces together for easier assembly.



Step two: Installation part

1. Clean the area where you are going to place the bottom board.



2. Follow the design manual, install the side board and backboard of the wardrobe to prevent it from becoming unstable or tilting.



3. Get a ladder ready in advance, place the top board on top of the side board, and fasten the two boards together using the cam lock and screw, afterwards screw the protective cap on the locking screw.



4. After the shelf is securely fixed, adjust the shelf, backboard and side panels to your requirements.



5. Inside the closet, install the alloy rails for drawers to slide along. Ensure all rails are properly installed before inserting the drawers.



6. Tighten the screws into the reserved positions and install the clothes bars in the appropriate positions.



Ending part:

Install the sliding doors.

Firstly install the tracks, then firmly secure the doors on the running tracks.

